



- Note 1: Termination Bar shall have an approved Duro-Last fastener within 1 inch of each corner. Utilize Detail Drawing 4010 with 3/4-inch #14 self tapping fasteners (by others) approved by FM 4470 testing.
- Note 2: Deck membrane shall be fastened around perimeter of roof penetration as per respective zone the skylight is located within (field, perimeter, corner).
- Note 3: All field welds shall be a minimum of 1-1/2 inches wide.
- Note 4: Fasten skylight flange with 1-1/4 inch roofing nails spaced 6 inches on center.
- Note 5: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: N/A	ROOF PENETRATION DETAIL FOR ADHERED NON-FLEECE SYSTEMS
PREVIOUS: 07/13/2023	SKYLIGHT DECK MOUNT PENETRATION
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF