



Note 1: If the mechanical units are of a size that they will crush the insulation, then the insulation below the sleeper must be replaced by wood blocking.

Note 2: Attach mechanical unit to sleeper per equipment manufacturer's instructions.

Note 3: All field welds shall be a minimum of 1-1/2 inches wide.

Note 4: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED:	N/A	ROOF PENETRATION DETAIL FOR ADHERED NON-FLEECE SYSTEMS
PREVIOUS:	11/22/2023	WOOD SLEEPER
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF