



Note 1: Appropriate Duro-Last termination must be followed.

Note 2: Backseal membrane with approved Duro-Last sealant. Position stainless steel band 1/4-inch from top of butterfly corner. Finish with bead of approved Duro-Last caulk along top edges of membrane and stainless steel band.

Note 3: Wood nailer must be installed below support if insulation is used.

Note 4: Wood nailers must withstand a minimum force of 180 pounds per lineal foot (per building code). Any pull values greater than 270 pounds will allow for a fastener spacing of 18 inches on center. Pull values less than 270 pounds will require additional fasteners. **The installing contractor is responsible for meeting building codes.**

Note 5: Refer to specifications for vapor barrier, insulation and cover board requirements.

Note 6: All field welds shall be a minimum of 1-1/2 inches wide.

REVISED:	N/A	ROOF PENETRATION DETAIL FOR ADHERED NON-FLEECE SYSTEMS
PREVIOUS:	12/14/2023	LADDER REST
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF