



INSTRUCTIONS

1. Install Two-Way Air Vents (vents) between fastener rows and at high points of roof area. Vents must not be installed within 7 feet of the building edge. Never install vents in low, or drainage areas.
 - a. A minimum of one vent must be installed for every 1,000 square feet of roof area, or portion thereof, but with a minimum of two vents per roof area.
 - b. Vent Placement
 - i. Corners - Vents must first be installed within 8 to 10 feet of the outer corners. Install vents at opposite corners whenever possible.
 - ii. Remaining Roof Area - Starting at 8 to 10 feet from the building edge, evenly distribute the remaining vents throughout the remaining roof area. (Smaller roof areas may not have additional vents.)
2. Cut a 7-inch diameter hole and a 2-inch slit in deck membrane. Rotate vent to allow feet to slide underneath deck membrane at slit (see drawing above). Do not fasten vent to roof deck.

Note 1: **Vents must NOT be used on refrigerated buildings, freezer buildings or adhered roofing systems.**

Note 2: Vents are not required on open-air structures (e.g. carports) or roofing systems with overburden (e.g. ballast, paver, vegetation, etc.).

Note 3: All field welds shall be a minimum of 1-1/2 inches wide.

Note 4: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 01/16/2019	VENT DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 02/02/2017	TWO-WAY AIR VENT
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF