



- Note 1: Fasten the vent base to the deck using four approved fasteners, 1-1/2 in. (38 mm) from each outside corner and penetrating at least 1 in. (25 mm) into the deck.
- Note 2: Apply caulk between the base and flashing within 1 in. (25 mm) of the top of the flashing, where the three turbine fasteners will be installed.
- Note 3: Attach the turbine component to the vent assembly with three equally-spaced approved fasteners along the bottom collar, penetrating a 1/2 in. (13 mm) minimum.
- Note 4: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.
- Note 5: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: 00/00/0000	VENT DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 02/24/2026	VADA VENT BY DURO-LAST
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF