



## INSTRUCTIONS

1. Fasten **T-Edge base** to hold in place. Allow for 1/8-in. (3 mm) gap between sections of T-Edge base. Install splice plates at each gap.
2. Apply an approved sealant on top of T-Edge base as shown above.
3. Attach **T-Edge hook strip** to T-Edge base ensuring that seams are staggered by a minimum of 12 in. (305 mm) between hook strip and base. Each hook strip section must overlap next section by 1 in. (25 mm). Fasten hook strip and base 6 in. (152 mm) on center with approved fasteners.

**Note 1: The use of this detail is not allowed on adhered applications.**

Note 2: This detail may also be used on parapets.

Note 3: If used in a gutter, back-seal membrane with an approved sealant and fasten 6 in. (152 mm) on center with approved fasteners. Refer to Detail T3050.

Note 4: T-Edge with a 4-in. (102 mm) face or greater requires a continuous cleat fastened a maximum of 12 in. (305 mm) on center. Use roofing nails that penetrate substrate by a minimum of 1-1/2 in. (40 mm).

Note 5: All field welds shall be a minimum of 1-1/2 in. (40 mm) wide.

REVISED: N/A	TPO METAL EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 06/17/2025	T-EDGE
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF