



INSTRUCTIONS

1. Install **Snap Coping corner cap** prior to installing straight lengths of **Snap Coping cap**. Refer to Detail T6056.
2. Place **snap cleats** approximately 2 in. (51 mm) from any parapet end. Fasten snap cleats per Detail T6056.
3. Place **snap cleats** along straight length of parapet on 60 in. (1,524 mm) centers. At middle of run, adjust location to fit a short Snap Coping cap length. Maximum snap cleat spacing is 60 in. (1,524 mm) on center. Fasten snap cleats per Detail T6056.
4. Install **splice plates** per Detail T6056.
5. Begin installing **Snap Coping cap** from ends, working inward to center, and leaving a 1/4-in. (6-mm) gap between coping sections for thermal expansion. There should be a snap cleat and splice plate at each Snap Coping cap joint, and at least one snap cleat in middle of each 10-ft (3-m) section. Install per Detail T6056.

Note 1: Allow for a 3/8-in. (10-mm) gap between snap cleat and roof-side parapet to allow Snap Coping cap to snap into place.

Note 2: All fasteners must penetrate into nailers by a minimum of 1-1/2 in. (40 mm).

Note 3: Refer to General Requirements for wood nailer requirements.

REVISED: N/A	TPO PARAPET DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 05/20/2025	SNAP COPING CAP
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF