



## INSTRUCTIONS

1. Install **Snap Coping corner cap** prior to installing straight lengths of **Snap Coping cap**.
2. Place **snap cleats** 12 in. (305 mm) from parapet corner ensuring that face with pre-punched holes is located on outside parapet of building. Pull pre-punched face of each snap cleat snugly against outside face of parapet. Install 2 roofing nails into pre-punched face of snap cleats. Install 4 hex head screws with neoprene washers into pre-punched holes located on top of snap cleats. See Detail T6055.
3. Place **splice plate** over center of each snap cleat. Do not fasten splice plate. Apply approved sealant along both long top edges of splice plate.
4. Hook crimped face of **Snap Coping corner cap** over nailed outside-face kick of snap cleat. Rotate Snap Coping corner cap over top of snap cleat. Press down on roof-side face of Snap Coping corner cap until it locks over roof-side kick of snap cleat.

Note 1: All fasteners must penetrate into nailer by a minimum of 1-1/2 in. (40 mm).

Note 2: Refer to General Requirements for wood nailer requirements.

REVISED: N/A	TPO PARAPET DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 05/20/2025	SNAP COPING CORNER CAP
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF