



Note 1: Install Duro-Last Parapet Flashing as per Detail Drawing 6010.

Note 2: Splice cleats are installed 24 inches on center using 4 approved Duro-Last fasteners. Splice cleats must be located at each joint.

Note 3: When more than 1 piece of Arched Coping is used, center final section at top of arch and overlap lower sections.

Note 4: Coping that is 16 to 24 inches wide will require a row of hexhead screws and neoprene washers installed along the center at 18 inches on center.

Note 5: Coping that is 25 inches or wider will require 2 rows of hexhead screws and neoprene washers installed 6 inches from each edge at 18 inches on center.

Note 6: Edges are pre-notched to allow for an overlapping joint. Apply an approved Duro-Last sealant at all joints as shown above.

Note 7: Hexhead screws must penetrate into nailer by a minimum of 1-1/2 inches.

Note 8: Wood nailers must withstand a minimum force of 180 pounds per lineal foot (per building code). Any pull values greater than 270 pounds will allow for a fastener spacing of 18 inches on center. Pull values less than 270 pounds will require additional fasteners. The installing contractor is responsible for meeting building codes.

REVISED:	08/03/17	EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS:	08/03/17	ARCHED COPING WITH SPLICE CLEAT
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF