



- Note 1: Use Duro-Bond plates to attach the insulation and/or cover board in the perimeter and corner areas. Minimum perimeter width is 8 feet (Drawing A).
- Note 2: Perimeter Area: Install 8 fasteners per 4x8 foot board or 4 fasteners per 4x4 foot board (Drawing A).
- Note 3: Corner Area (minimum 8x8 foot): Install 10 fasteners per 4x8 foot board or 5 fasteners per 4x4 foot board (Drawing A).
- Note 4: Once rolled out, the membrane in the perimeter and corner areas shall be induction-welded to the Duro-Bond plates using induction welding techniques (Drawing B).
- Note 5: Contact the Duro-Last® Engineering Services Department for assistance in determining the fastening requirements if: the building is 40 feet tall, or taller; or the building is located in an area with an ASCE 7-05 design wind speed of 110 mph, or higher (150 mph, or higher, for ASCE 7-10); or fastener pullout resistance is less than 150 lb.

REVISED: 02/03/2017	MECHANICALLY FASTENED SYSTEMS FOR 120-INCH ROLL GOODS
PREVIOUS: 08/01/2012	PERIMETER FASTENING WITH DURO-BOND® SYSTEM (4 X 8-FOOT BOARDS)
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF