



INSTRUCTIONS

1. Fasten **T-Edge base** to hold in place. Allow for 1/8 in. gap between sections of T-Edge base. Install splice plates at each gap.
2. Apply an approved sealant on top of T-Edge base as shown above.
3. Attach **T-Edge hook strip** to T-Edge base ensuring that seams are staggered by a minimum of 12 in. between hook strip and base. Each hook strip section must overlap next section by 1 in. Fasten hook strip and base 6 in. on center with approved fasteners.

Note 1: The use of this detail is not allowed on adhered applications.

Note 2: This detail may also be used on parapet walls.

Note 3: If used in a gutter, back-seal membrane with an approved sealant and fasten 6 in. on center with approved fasteners.

Note 4: T-Edge with a 4 in. face or greater requires a continuous cleat fastened a maximum of 12 in. on center. Use roofing nails that penetrate substrate by a minimum of 1-1/2 in.

Note 5: All field welds must be a minimum of 1-1/2 in. wide.

REVISED: 10/31/2025	METAL EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 04/20/2017	T-EDGE
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF