

DURO-TECH TPO-COATED DRIP EDGE

DESCRIPTION:


Duro-TECH TPO-Coated Drip Edge ("Drip Edge") is used with Duro-TECH™ thermoplastic polyolefin ("TPO") roofing systems to prevent moisture permeation and to control the flow of water away from fascia and siding materials.

Drip Edge is fabricated using Duro-TECH TPO-Coated Metal and pre-punched every 6 inches (152 mm) on center. A reinforced TPO membrane skirt is factory-attached to allow for heat (hot-air) welding to TPO deck or parapet membrane.

ORDERING:

Drip Edge is 10-feet (3-m) long and available in a variety of face sizes, ranging from 2 – 8 inches (51 – 203 mm), each with a 3/8-inch (10-mm) hemmed kick. A cleat is required for a 4-inch (102-mm) face or greater.

- Custom sizes and color combinations are available.



STORAGE AND HANDLING:

- Keep away from ignition sources.
- Always store in a dry location protected from the elements.

PRECAUTIONS:

- Keep away from ignition sources.
- Wear proper personal protective equipment, such as gloves and eye protection, per the SDS.



INSTALLATION:

Installation must be completed in compliance with the appropriate Duro-TECH TPO details and specifications.

1. With a 4-inch (102-mm) face or greater, a continuous cleat is required. Fasten the cleat 6 inches (152 mm) on center with roofing nails that penetrate the substrate by at least 1-1/2 inches (38 mm).
2. Prepare all affected surfaces to be welded with an approved TPO membrane cleaner, if necessary.
3. Fasten the Drip Edge to the deck using approved fasteners, spaced a maximum of 6 inches (152 mm) on center.
4. Overlap adjoining Drip Edge sections by 1-1/2 inches (38 mm).
5. Position the attached TPO membrane skirt and heat (hot-air) weld to the TPO deck or parapet membrane, with a minimum 1-1/2-inch (40-mm) weld.