

DURO-SHIELD® REINFORCED ROOF REPAIR (R3)

DESCRIPTION:

Duro-Shield® Reinforced Roof Repair ("R3") is a flashing-grade, standalone silicone roof patch, designed to be installed in a single application, without additional reinforcement, for low-slope applications prior to applying Duro-Shield primers and coatings.

Fabric may be included for additional reinforcement at angle changes or irregularly shaped penetrations, if desired.

R3 is a thick, caulk-like material which can be used to correct surface cracks, control joints, coping joints, gutter seams, membrane pinholes, rain collars, and fish mouths with the following roof substrates:


- Aged single-ply membranes:
 - PVC (polyvinyl chloride)
 - EPDM (ethylene propylene diene monomer)
 - TPO (thermoplastic polyolefin)
- Concrete
- Galvanized steel, aluminum, Galvalume®
- Sprayed polyurethane
- Most existing elastomeric roof coatings
 - Existing silicone coatings should **not** be primed.
- Aged asphaltic membranes, including:
 - APP (atactic polypropylene)
 - SBS (styrene butadiene styrene)
 - Smooth BUR (built-up roofing)
 - Mineral surface cap sheets

ORDERING:

Refer to Application step 3.c. for approximate coverage rates. Refer to the Duro-Shield Silicone Roof Coating Installation Guide located on the Duro-Last® website for additional application guidelines. Additional colors and sizes available upon request. Restrictions apply.

R3 is available in 2-gallon (7.6-L) containers.

- White (Item #4191102)
- Tan (Item #4191102T)
- Gray (Item #4191102G)
- Black (Item #4191102B)



STORAGE AND HANDLING

- **WARNING: EXTREMELY FLAMMABLE.**
Keep away from heat / sparks / open flames / hot surfaces. **Do not apply while smoking.**
- Store product out of direct sunlight, tightly closed in a dry, cool, and well-ventilated place.



SHELF LIFE

Shelf life of 2 years from date of manufacture when stored in original, unopened container between 0° – 75° F (-18° – 24° C).

- Shelf life will be shortened if exposed to elevated temperatures.

DURO-SHIELD REINFORCED ROOF REPAIR PROPERTIES		
	Test Method	Results
VOC Content	SCAQMD 1168	< 2.1 lbs/gal (< 250 g/L)
Viscosity	#2 spindle @ 20 rpm	≤ 200 cps
Solids by Weight (GP1500)	4041	80%
Solids by Volume (GP1500)	4041	68%
Flash Point	ASTM D93	103° F (39.4° C)
Cure Time	—	Moisture cure Tack free: 4 hours Fully cured: 40 hours

PRECAUTIONS:

- **WARNING: EXTREMELY FLAMMABLE.**
Keep away from heat / sparks / open flames / hot surfaces. **Do not apply while smoking.**
- **KEEP AWAY FROM CHILDREN.**
- **NOT WATER-SOLUBLE.** Water will gel this product.
- Do **not** use colored silicones over asphaltic substrates.
- Use **only** outdoors or in well-ventilated areas.
- Keep container closed when not in use.
- Keep away from edible substances and potable water storage systems.
- Read Safety Data Sheets ("SDS") prior to using. SDS can be found at:
<https://www.duro-last.com/duroshield>.
- Wear proper personal protective equipment, such as gloves and eye protection, per the SDS.
- Avoid breathing vapors.

INSTALLATION:

Labor & Material Warranties are available. Please contact your Duro-Shield Representative for requirements.

1. General

- Do **not** thin this product.
- Do **not** apply to substrates below 32° F (0° C) or above 120° F (48.9° C).
- Adhesion tests are recommended. Prime where necessary.
- Application method, as received:
 - Brush
 - Trowel
 - Putty knife

2. Substrate Preparation, Cleaning Procedures, and Seam Treatment Prior to Coating

- Refer to the Duro-Shield Silicone Roof Coating Installation Guide.

3. Installation

- a. Do **not** thin this product.
- b. Mix R3 thoroughly before use. A mechanical mixer is required to ensure sufficient mixing of contents. Product will appear uniform and free of lumps after mixing. **Do not use a paint shaker to mix.**
- c. Apply R3 at the following coverage rates:
 - 4-inch (102-mm) wide, crested and centered at the seam, with a minimum thickness at the center of 64 wet mils (1.6 mm) for coverage of approximately 70 LF/gal (5.6 Lm/L).

Note: Application rate is job-specific. Additional material may be required.
- d. Allow R3 to dry for at least 4 hours, until a tack-free state is achieved.
- e. Sacrificial tape may be used and is recommended for repairing cracks more than 1/4 inch (6 mm), and any transitions that are subject to movement.

CLEANUP:

Clean R3 application tools and equipment with virgin mineral spirits. **DO NOT USE WATER OR RECLAIMED SOLVENTS.**